

Lecture Presentation

Nuclear Magnetic Resonance Logging

Advanced Multi-Well Formation Evaluation
Lecture Notes

Fundamentals of Nuclear Magnetic Resonance Borehole Logging

Carlos Torres-Verdín, Ph.D.

Professor


Department of Petroleum and Geosystems Engineering

The University of Texas at Austin



Objectives:

1. To introduce the basic physical and operational principles of NMR borehole logging,
2. To learn how to interpret NMR measurements made on rocks in terms of petrophysical properties,
3. To understand the advantages and limitations of NMR borehole logging with respect to conventional borehole logging measurements, and
4. To learn how to combine NMR measurements with rock-core data and standard borehole logs.


WILL THE WELL PRODUCE?




Porosity = 20%
Permeability = 7.5 md



Porosity = 19.5%
Permeability = 279 md



FREE FLUID vs. IRREDUCIBLE FLUID





High Permeability Grainstone




Low Permeability Wackestone







Logging Tools




NMR vs. NEUTRON and/or DENSITY




SPIN MAGNETIZATION



SPIN MAGNETIZATION



PRECESSION



Arnold Sommerfeld
1868 – 1951,
teacher of Heisenberg:
described the spinning top

Paul Adrien
Maurice Dirac
1902 – 1984,
1933 Nobel prize in Physics:
postulated the existence of the spin

Otto Stern
1888 – 1963,
1943 Nobel prize in Physics:
experimental discovery of the spin

Nuclear Spin

precession frequency
 v_t

gravitation
 mg

angular momentum

magnetic moment
 $\mu = \gamma \hbar I$

magnetic field $B_0 = \begin{bmatrix} 0 \\ 0 \\ B_0 \end{bmatrix}$

Larmor frequency v_0


atomic nucleus

Macroscopic Magnetization

macroscopic sample:
 10^{23} nuclear spins

$$n/n_+ = \exp\{-\Delta E/k_B T\}$$

vector sum:
macroscopic
magnetization \mathbf{M}



100 000 000 000 000 000 000 proton spins in a drop of water

LARMOR FREQUENCY

... the frequency at which the nuclear spin precess about the external static magnetic field

$$\nu_0 = \frac{\gamma}{2 \cdot \pi} \cdot B$$

γ gyromagnetic ratio

B static magnetic field

Nucleus	$\gamma/2\pi$ MHz/Tesla
^1H	42.58
^{13}C	10.7
^{23}Na	11.26

^1H

ELEMENTAL NMR RESPONSE

Nucleus [most common applications in log & core analysis]	$\gamma/2\pi$ (Hz/Gauss)	I	Natural abundance (%)	Relative sensitivity
^1H [core and log]	4257.59	1/2	99.99	1.000
^2H [aqueous phase]	653.57	1	0.015	0.0097
^{13}C [need high freq.]	1070.5	1/2	1.10	0.0159
^{19}F [nonwetting phase]	4005.5	1/2	100.00	0.833
^{23}Na [salinity]	11.26	3/2	100.00	0.0925

LARMOR FREQUENCY

Tuning the NMR tool to the resonant frequency
maximizes the signal amplitude

Larmor frequency is proportional to


$$\nu_0 = \frac{\gamma}{2 \cdot \pi} \cdot B$$

- magnitude of the static magnetic field
- gyromagnetic ratio of the nucleus


different species can be
differentiated/separated
on the basis of
frequencies

Strength is position
dependend - local
function


FREQUENCY- INTENSITY SPECTRUM




TRANSVERSAL TIPPING




NMR Longitudinal Relaxation and Fluid Distribution in the Pore Space




TRANSVERSAL TIPPING



TRANSVERSAL TIPPING and PROTON PRECESSION




LONGITUDINAL AND TRANSVERSE RELAXATION



- Two primary parameters that control NMR logging, TE and TW .

LONGITUDINAL AND TRANSVERSE RELAXATION




Two relaxation types → two relaxation times:


- T_1 - longitudinal, or spin-lattice, relaxation time
- T_2 - transverse, or spin-spin, relaxation time

BASIC NMR INSTRUMENTATION COMPONENTS


- A time-constant magnetic field used to polarize the spins
- A time-varying RF magnetic field to excite the spins
- A magnetic receptor to measured the spin response




NMR is a Form of Radio-Frequency Spectroscopy




NMR EXPERIMENTAL TIMING



NMR DEPHASING OF SPINS (SPIN-SPIN RELAXATION)




GRADIENT FIELD MEASUREMENTS (SPATIAL GRADIENT IN THE STATIC MAGNETIC FIELD) DEPHASING EFFECT



EXTERNAL and INTERNAL FIELD GRADIENTS

External Gradient


- Depends on the magnets' configuration. Negligible in laboratory experiments.




Internal Gradient

- Arises because of the difference in magnetic susceptibility between the matrix and the fluid.
- Depends on both the pore geometry and the type of rock.
- Important in porous media.
- Proportional to the RF frequency


$$G \sim \frac{\Delta\chi \cdot B_0}{r_{pore}}$$




A SINGLE SPIN ECHO




NMR SPIN ECHO SEQUENCE (CPMG SEQUENCE)




NMR SPIN ECHO SEQUENCE (CPMG SEQUENCE)





THE PROCESS OF DEPHASING: A RUNNER'S ANALOGY

IDEALIZED CMPG SPIN-ECHO TRAIN



SUMMARY: CMPG SPIN ECHO SEQUENCE

Step 1: $B_0 \rightarrow$ Proton alignment

Step 2: $B_1 \rightarrow$ Proton 90° tipping

result: precession

Step 3: Precessing and dephasing as a result of B_0 inhomogeneity /gradient field

result: partial loss of synchronization


Step 4: $B_1 \rightarrow 180^\circ$ refocusing

result: partial reversible dephasing,
signal measured as „spin echo“



... step by step coherent magnetization decreases ---> relaxation

COMMERCIAL NMR WIRELINE TOOLS

MRIL




CMR



Gradient field vs. Homogeneous B_0

MODERN MRIL WIRELINE TOOL (MANDREL TOOL)



WIRELINE MRIL TOOL

NUMAR C/TP Configuration




Baker Atlas C/TP Configuration 20' shorter



WIRELINE MRIL TOOL: Mud Excluder

Fiberglass sleeve to displace mud


Sizes: 7.25" and 9"



MRIL TOOL SPECIFICATIONS:


- Maximum Operating Temperature- 310°F (155°C) for 5 hours
- Maximum Pressure-20,000 psi (137MPa)
- Tool Diameter-4.5" magnet and 6" magnet
- Measuring Range-0 p.u. to 100 p.u.
- Accuracy (MHPI, MBVM, MBVI) $\pm 5\%$ or 1 p.u.
- Repeatability (MPHI, MBVM, MBVI) 1 p.u. standard deviation of measured porosity
- Logging Speed Dependent on Formation T1 and Sampling Rate
- Borehole Diameter Range
 - 4.5" magnet - 5" to 7.5" BHD
 - 6" magnet-7.5" to 12.25" BHD
- Minimum Vertical Resolution-24 inch aperture
- Maximum Borehole Deviation-90° deviation (PCL)

MULTIPLE FREQUENCY, HIGH RESOLUTION MRIL TOOL




MULTIPLE FREQUENCIES

Larger Volume of Investigation or Simultaneous Experiments




CALIBRATION



MRIL CALIBRATION


- The calibration is performed in a fiberglass borehole and formation simulator enclosed in a Faraday cage. (Frequency of 60 - 90 days)
- It is a single point calibration for 100% porosity in fresh water ($\text{HI} = 1$).
- The calibrator is also logged to check tool stability at $100\% \pm 2\%$ before and after job.
- At the well site the tool is checked with a “Electronics Verifier”. The box simulates the magnet to perform a check on the transmitter and electronics functions. Continuity and insulation checks are done on the magnet/antenna .

MRIL CALIBRATION: FREQUENCY SWEEP




Peak Frequency : In dual frequency mode the MRIL tool will operate at the peak frequency +/- 6kHz.


MRIL SENSITIVITY VOLUME



MRIL SENSITIVITY VOLUME




SENSITIVITY VOLUME IN THE INVADED ZONE




MRIL primarily measures in the flushed zone where invasion alters the native fluid saturation. Additives in the mud system may alter wettability.

MRIL SENSITIVITY VOLUME (Effect of Temperature)




CENTRALIZATION



ECCENTRICITY EFFECT

Sensitive Volumes





Centralized


Not Centralized

Decentralization results in a sensitive volume that intersects the borehole.


SCHLUMBERGER'S CMR, CMR-200, CMR-Plus




Tool Description



SCHLUMBERGER'S CMR TOOLS




CMR-200 and CMR-Plus
Sonde Cross Section



Both tools use the same cartridge but the CMR-Plus has an extra 18 inch magnet section

TOOL SPECIFICATIONS




CMR-Plus

- Logging speed
 - Long T_1 800 ft/hr
 - Short T_1 3600 ft/hr
- Length 15.6 ft
- Weight w/ bowspring 413 lbm
- Minimum hole size 5 $\frac{7}{8}$ in.
- Vertical resolution (three-level) 24 in.


CMR-200 and CMR-Plus

- Measurement aperture 6 in.
- Max pressure 20 and 25 kpsi
- Max temperature 350°F
- Echo spacing 200 μ s
- Depth of investigation 1.1 in.
- Mud resistivity No limit

NMR PULSE SEQUENCE




PHASE-ALTERNATED PAIR



- Two CPMGs of opposite phase
- A phase-alternated pair (PAP) cancels electronic offsets and 180° ringing.


Overlapping vs. Non-Overlapping CPMGs

CMR-200 or CMR-Plus



Overlapping CPMGs

CMR-Plus




Non-Overlapping CPMGs

Typical CMR-Plus Acquisition Sequences and Logging Speeds


T_1	Polarization Time (s)	Number of Echoes	Sample Interval (in.)	Logging Speed (ft/hr)	
				Standard	EPM
Short (0–0.5 s)	1.4	600	7.5	3600	1800
Medium (1–2 s)	7.3	1800	7.5	1500	1200
Long (3–4 s)	13.5	3000	7.5	800	700

Enhanced Precision Mode


- Special multi-wait-time (MWT) pulse sequence
 - One long wait-time subsequence (WT1 = 1–12 s)
(measures all T_2 components)
 - Ten short wait-time subsequences (WT2 = 0.02 s, 30 echoes)
(measure the early T_2 components)



Schlumberger's Latest Wireline NMR Tool



MRX Design




MRX: Eccentered Gradient design

- Sample volume in thin shells
- Deeper and well defined DOI
- Depth log MRF
- Tuning is simple
- High-end NMR applications

NMR Wireline Tool Summary


Vendor		Halliburton		Schlumberger		BakerHughes
Toolname		MRIL Prime		CMR+	MRX	MREx
Diameter	in	6	4.7/8	6	5	5
Borehole min	in	7	6	6	5.7/8	5.7/8
Borehole max	in	16	8.5	na	na	na
DOI	in	~ 4		1	1.5 - 4	2.4 - 4.4
Max temp	F	350		350	300	350
Gradient	G/cm	18		wide	30 - 10	34 - 11
Frequency	kHz	600		2200	1000-500	900-450
# shells		9		1	≥ 4	≥ 6
Antenna length	in	24		6	7.5	24
Shortest TE	ms	0.6		0.2	0.45	0.4
Max # echoes		1000		8000	(>) 1000	(>) 1000
Max logging speed	ft/hr	1500		1800	1800	1400
Position		centred		pad	pad	pad
Mud effect on noise		strong		low	low	low

Logging-While-Drilling NMR



Logging-While-Drilling NMR

proVISION Cutaway



Wearbands


Optional stabilizer

Antennas

Schlumberger

BASIC INTERPRETATION OF NUCLEAR MAGNETIC RESONANCE DATA

LONGITUDINAL AND TRANSVERSE RELAXATION




T_w = wait time

T_E = inter-echo time


T_1 = Longitudinal magnetization build up

T_2 = Transverse magnetization decay


NMR Longitudinal Relaxation and Fluid Distribution in the Pore Space




T1 BUILD-UP OF OILS




T1: TEMPERATURE DEPENDENCE



T1: CRUDE OILS



T1: PRESSURE DEPENDENCE




C.J. Gerritsma, P.H. Oosting, N.J. Trappeniers
"Proton Spin-Lattice Relaxation
and Self Diffusion in Methanes, II"
Physica, 51, 381-394 (1971)

NMR TRANSVERSE RELAXATION IN WATER-FILLED PORES

Diffusion and surface relaxation
in an isolated, water-filled pore


slow-relaxing spins
in pore space, V




fast-relaxing spins in thin film on
pore surface S, film thickness l ~
10 Å

$$\frac{1}{T_2} = \rho \frac{S}{V} + \frac{1}{T_{2b}} + \frac{1}{T_{2D}}$$

NMR Transverse Relaxation and Pore Size Distribution




NMR Transverse Relaxation and Pore Size Distribution




TRANSVERSE RELAXATION

Amplitude Decay Explanation



Gradient Field and Diffusion



Diffusion during the pulse sequence causes a reduction in signal amplitude with time and decreases T_2 .

CARR-PURCELL GRADIENT FIELD RELAXATION RATE

$$\frac{1}{T_{2(CPMG)}} = \frac{1}{T_2} + \frac{D(\gamma G T_E)^2}{12}$$

T_2 = Intrinsic Relaxation Rate (sec)


G = Static Magnetic Field Gradient (gauss/cm)

γ = Gyromagnetic Ratio (0.678 radians/gauss)

T_E = Pulse Echo Spacing (sec)

D = Diffusion Coefficient (cm^2/sec)



CARR-PURCELL GRADIENT FIELD RELAXATION RATE




BULK (T₂) and GRADIENT (D) DIFFUSIVITY Relationship with Fluid Viscosity

$$D = \frac{1.3T_K}{298\eta} \quad T_{1\text{bulk}} \approx T_{2\text{bulk}} = \frac{1.2T_K}{298\eta}$$

Vinegar, 1995



GAS RELAXATION




Tool Gradient: $G = 20 \text{ Gauss/cm}$
Unrestricted Diffusion of Gas

SUMMARY: RELAXATION MECHANISMS

		T_1	T_2	T_1/T_2
Mineral Hydrogen		10-100 sec	10-100 μsec	$\sim 10^6$
Water	Clastic	Surface Dominated	Surface Dominated	$T_1/T_2 = \xi$ $\xi \sim 1.5$
	Vugs	Bulk*	Bulk/ Diffusion*	$T_1 \geq T_2$
Oil	Medium to Heavy	Bulk*	Bulk*	$T_1 = T_2$
	Light	Bulk*	Bulk/ Diffusion*	$T_1 \geq T_2$
Gas		Bulk*	Diffusion*	$T_1 \gg T_2$

(*) Independent of formation. Consult appropriate chart.

RELAXATION TIMES FOR CRUDE OILS



Elements of T2 Decay

(Wetting Phase Saturation = 100%)

Surface Relaxivity

Pore Surface Area to Volume Ratio


$$\frac{1}{T_2} = \rho \left(\frac{S}{V} \right) + \frac{1}{T_{2b}} + \frac{1}{T_{2D}}$$

Bulk Fluid Relaxivity


Diffusion Decay

Primary Controls on T₂ Decay


(Wetting Phase Saturation = 100%)



The Interplay between NMR Transverse Relaxation, NMR Gradient Diffusion, Pore Size Distribution, and Fluid Distribution



The Interplay between NMR Transverse Relaxation, NMR Gradient Diffusion, Pore Size Distribution, and Fluid Distribution



SURFACE-to-VOLUME RATIO

$$\frac{1}{T_2} \approx \rho \frac{S}{V} \propto \rho \frac{1}{length}$$

Sphere



$$\frac{S}{V} = \frac{4\pi r^2}{\frac{4}{3}\pi r^3} = \frac{3}{r}$$


T_2 is proportional to
pore size

Cylinder



$$\frac{S}{V} = \frac{2\pi rh}{\pi r^2 h} = \frac{2}{r}$$


Fracture




$$\frac{S}{V} = \frac{2Ah}{Ah\delta} = \frac{2}{\delta}$$

T_2 Decay and Pore Size

(Wetting Phase Saturation = 100%)





RELATIONSHIP WITH POROSITY, Quantification Procedure





Single Exponential Decay

$$y = \text{por} \cdot e^{-t/T_2}$$




Multi-exponential Decay


$$\mathcal{Q} = \sum \text{por} \cdot e^{-t/T_2}$$




NMR DATA INVERSION: SUM OF EXPONENTIALS




T₂ RELAXATION AND PORE SIZE




T₂ RELAXATION AND PORE SIZES



TOTAL POROSITY vs. FRACTIONAL POROSITY



INVERSION OF ECHO DATA



SPECIFIC SURFACE AREA FOR COMMON ROCK TYPES

Material	[m ² /g]
Pure Quartz Crystals	0.15•10 ⁻⁴
Quartz Spheres	60 μm
	30 μm
	2 μm
	1 μm
Crushed Quartz	3.1
Kaolinite	10- 40
Illite	30 - 70
Smectite	550 - 750
Limestone (Trenton & Caddo Form)	0.1 - 0.35
Gulf Coast Shaly Sands (V _c ~ 15 - 30%)	100 - 450

Source of Data

Zemanek, 1989

Carman, 1956

Brooks and Purcell, 1952

Almon and Davies, 1978

COMPARISON OF DISTRIBUTIONS

Sandstone

Kair = 2.15 md

Porosity = 9.7 p.u.

ρ_e = 23.0 $\mu\text{m/sec.}$

Dolomite

Kair = 7.41 md

Porosity = 15.8 p.u.

ρ_e = 5.35 $\mu\text{m/sec.}$


Limestone

Kair = 12.3 md

Porosity = 10.5 p.u.

ρ_e = 3.16 $\mu\text{m/sec.}$

--·· Pc Pore throat dist.
— NMR Pore body dist.






NMR PROPERTIES: CLAY MINERALS

Clay mineral	Specif. Internal Surface m ² /g	Cation Exchange Capacity CEC meq/100g	T ₂ ms
Montmorillonite	760	76	0.3 ... 1
Illite	93	15	1 ... 2
Kaolinite	18	4	8 ... 16

Effect of Pore Size on T₂ Spectra

(Wetting Phase Saturation = 100%)



Surface Relaxivity and T₂ Decay

Controls on Surface Relaxivity ρ

- Pore surface mineralogy
- Para, ferri, and ferro-magnetic ions (e.g., Fe³⁺, Mn²⁺)
- Wettability

Effects of ρ Variations (Wetting Phase Only)



- Higher ρ results in faster T₂ Decay
- Lower ρ results in slower T₂ Decay

Surface Relaxivity and T_2 Decay

(Wetting Phase Saturation = 100%)

— Low ρ (Carbonates)

— High ρ (Clastics)





Surface Relaxivity and T_2 Decay

2-phase Fluid System, Wetting Phase
@ Irreducible Saturation

— Low ρ (Carbonates)



— High ρ (Clastics)




Effect of Magnetic Ions on T_2 Decay

The presence of Para, ferri, and ferro-magnetic ions (e.g., Fe^{3+} , Mn^{2+}) will increase ρ and produce internal magnetic field gradients which attenuate echo amplitudes due to accelerated diffusion decay (T_{2D}).


— Mineral Constituents with Low Magnetic Susceptibility
— Mineral Constituents with High Magnetic Susceptibility





Pore Volumetric Distribution




WILL THE WELL PRODUCE?




Porosity = 20%
Permeability = 7.5 md




Porosity = 19.5%
Permeability = 279 md




FREE FLUID vs. IRREDUCIBLE FLUID





GAS EFFECT




NMR TRANSVERSE RELAXATION: An Overview




Basic NMR Field Deliverable




FIELD LOG EXAMPLE




THIN,
LAMINATED-
BED
ANALYSIS




THIN, LAMINATED- BED ANALYSIS



THIN, LAMINATED- BED ANALYSIS




THIN, LAMINATED- BED ANALYSIS




Patagonia Example


		CLAY BOUND					
		BIN 5					
		BHF					
		BIN 1					
		BIN 2					
		BIN 3					
		BIN 4					
		BIN 6					
	Revoque From HCAL to BS	BIN 7					
	Caverna From BS to HCAL	BIN 8					
SP (SP) (MV)		Total CMR Porosity (TCMR) (V/V)			Permeability - CMR		
-110	-10	0.4		0			
RWA-CMR (LC05)		CMR Free Fluid (LC07)			T2 LOG Mean (T2LM)		
0	(---)	1.0	0.4	(---)	0	0.1	(MS) 1000
Caliper (HCAL)		CMRP_3MS (LC06)			Permeability - CMR (LC08)		
6	(IN)	16	0.4	(---)	0	0.1	(---) 1000
Tension (TENS) (LBF)	Bit Size (BS) (IN)	Std. Res. Density Porosity (DPHZ)		Permeability - Timur/Coates (KTIM) (MD)		BOUND FLUID Cutoff For T2 Distribution (LOG-T2CUTOFF)	
1000	16	0.4	(V/V)	0	0.1	1000	0.3 (MS) 3000

Patagonia Example



Patagonia Example






NMR T_2 Distributions



Typically, use a 33-ms cutoff for T_2 in sandstone.

T_2 distributions show a distinct bimodal distribution characteristic of bulk relaxation of the oil-based mud filtrate invasion.


The 33-ms line on the T_2 distribution is below valley separating bulk free fluid from free fluid volume.



Influence of OBM Filtrate



Results: Improved Permeability Transform



SUMMARY: HYDROCARBON EFFECTS ON NMR

In a water wet rock that contains hydrocarbons :

- **The T2 distribution does not contain pore size information. However, the MBVI may still be correct.**
- **T2 geometric mean-based permeability estimation does not work.**
- **MBVM/MBVI-based permeability estimation works when logs are corrected for hydrocarbon effects.**

SUMMARY: HYDROCARBON EFFECTS ON NMR

Fluid Type	HI	T1	T ₂ component
light to moderate viscosity oil (<40 cp)	≈1	long	MBVM
heavy oil	≈1	short	→ MBVI
gas	<1	long	MBVM or MBVI*

* depends on tool frequency and environmental conditions

SUMMARY: FORMATION AND FLUID EFFECTS

- Clay Reduces MPHE-bound water relaxes too fast to detect with standard T₂, can be measured with C/TP.
- Gas Low HI reduces MPHE; long T₁ but short T₂ due to diffusion
- Light oil Long T₁ increases TW, reduces logging speed; complicates application of mean type permeability models.
- Heavy oil Fast T₂ decay of oil signal complicates MBVM/MBVI interpretation.
- Thin beds Thin beds are not resolved. However, the volumetric porosity and permeability are still correct.

SUMMARY: ENVIRONMENTAL EFFECTS

Temperature	Reduces depth-of-investigation
Conductive mud	High Q loading reduces SNR, (logging speed); Interference signal from sodium
Washout $> D_{MRIL}$	M PHI too high, excess (mud) signal, usually in MBVI
Invasion	Alters native fluid saturations; primarily measures the flushed zone

SUMMARY:

Petrophysical Applications of NMR Data

- Mineralogically-Independent Porosities (Total & Effective)
- Clay-Bound Water Volume
- Capillary-Bound Water & Free Fluid Volumes
- Pore Size Distribution (Single Phase Fluid Saturation)
- Permeability (With calibration to core or test data)
- Shale Volume & Distribution
- Flushed Zone Fluid Saturations (DTW analysis)
- Hydrocarbon Viscosity (DTE analysis)
- Electrical Properties & Water Saturation (Integrated Products)

Acknowledgements:

Baker Atlas
Schlumberger
Halliburton